



Installation of the Boss Frog Bolt-In Harness Bar

Congratulations on the purchase of your Boss Frog Bolt-In Harness Bar. Installation is fairly simple, but following are a few guidelines;

Tools needed: 5/8" wrench or socket, and two 9/16" wrenches.

1. Be very careful when inserting the Harness Bar into position, to avoid damaging the powdercoat finish on either the Harness bar or the rollbar.
2. Remove the 7/16" seat belt tower bolts using a 5/8" socket or wrench. Also remove the 3/8" bolts holding the seat belt guides using 9/16" wrenches. If the rollbar was



- correctly installed, then it should not move when the seatbelt tower bolts are removed.
3. Position the Harness Bar with the flat side of the brackets up, and the horizontal bar towards the rear of the car. Start one of the 7/16" bolts on one end, and then insert the 7/16" bolt in the opposite end. If the second bolt does not go into the hole easily or vertically, you may need to file the slot slightly. This is due to variations in the distance between seatbelt towers.
4. With the 7/16" bolts both started, reattach the seatbelt adapters through the slot in the harness bar. Depending on your configuration, you may need to use 3/8" x 1-1/4" grade 8 bolts instead of the 1" long bolt supplied with the rollbar. Do not use fasteners less than grade 8.
5. After all bolts are started, tighten up all the bolts and nuts.

Thanks for buying a Boss Frog!

Note – these fasteners must remain tight to retain their designed strength. Check all bolts after a few weeks of operation, and always keep them tight.