



Installation of the Boss Frog Clearview Vinyl Cover

Congratulations on the purchase of your Boss Frog Vinyl Cover. Installation requires cutting the holes for the braces, because there is some variation between rollbars. Following is the suggested method;

1. The vinyl covers will only fit properly over the Boss Frog padding. Make sure this is properly installed first.
2. Lay the cover over the top of the rollbar. The sewn seam should be roughly on top, just in behind the top edge of the padding, so that it will lay fairly flat. The cover should also be centered from end to end. Most people prefer that the top overlapping part of the Velcro be on the front side, so that the seam doesn't show as much.
3. Start with the inner brace legs at the center of the rollbar. Using the 1-3/4" circle template, place the top edge of the template on the top part of the brace weld. Hold the template in position, center it carefully on the brace, and mark the circle onto the cover with a light colored pencil or marker. Mark both of the inner braces.
4. Carefully cut the marked circles with a scissors. You will need to cut through the Velcro edge. Wrap the cover tightly around the bar and Velcro the center portion into place. Attach the Velcro seam together as far as possible toward the outside corners.
5. The top of the cover over the curved part of the hoops will be wrinkled. This can be straightened out by pulling on the end of the cover, toward the ends of the padding. Pull the cover into place as much as possible without displacing the center portion already cut. With the cover fairly tight from end to end, and the top sewn seam just behind the top edge of the padding, repeat the procedure of marking and cutting the brace holes in both corners. Attach the Velcro around the underside the full length of the cover.
6. The cover must be stretched from end to end to make it lay as flat as possible. While holding the middle of the cover stationary, pull one end of the cover until most of the wrinkles are out of the cover. Mark this point on the pad. Cut the pad at this mark, or even a bit longer than the mark. Tie the cord tightly around the end of the pad, and repeat for the other side.
7. The cover may need a little tweaking to get the wrinkles out, but it should lay fairly flat. The sun will also help to relax the cover into the shape of your rollbar.

Thanks for buying a Boss Frog!

