



Installation of the Boss Frog Double Hoop Windblocker

Congratulations on the purchase of your Boss Frog windblocker. Installation is very simple, and can be accomplished a number of different ways. Following is the suggested method;

1. There is a two lengths of high strength velcro furnished with the windscreen, a hook side and a loop side. Cut each velcro strip into 4 equal parts, then attach the hook and loop sides together in pairs, with the adhesive sides facing apart from each other.
2. Carefully remove the protective plastic from the windblocker. Temporarily place the windblocker in position, centered and behind the center legs of the hoops. The notches on the lower corners should rest on the horizontal cross braces of the rollbar.
3. Mark the top edge of the windblocker on the back of the hoop legs, using masking tape or a pencil.
4. Remove the windblocker. Remove the adhesive backer from one side of one velcro pair and attach to the back side of a hoop leg, approximately 1" down from the marks. Repeat on the other side.
5. Remove the adhesive backer from two more velcro pairs, and attach to the back side of the hoop legs, about 1" above the horizontal brace.
6. Remove the adhesive backers on all the velcro pairs now attached to the rollbar hoops, and carefully position the windscreen on the adhesive pads, pressing firmly against the hoops.
7. Note that the adhesive will take some time to cure, and the windscreen should not be removed until the adhesive has firmly attached to the hoops and windscreen.
8. If you have the vinyl pads and covers, the Velcro can be attached to the vinyl cover instead of the rollbar hoops.



Thanks for buying a Boss Frog!