



Installation of the Boss Frog Double Hoop Padding & Vinyl

Congratulations on the purchase of your Boss Frog products. Installation is very simple, and can be accomplished a number of different ways. Following is the suggested method;

Padding

- Your new padding is custom made for your double hoop rollbar. One of the pads is a right-hand, and the other is a left-hand. Test fit them to see which pad fits on which hoop.
- When test fitting the pads, push the top of the pad tight against the rollbar. Look inside the hoop where the vertical brace meets the hoop, to see if the pad needs to be trimmed.
- If trimming is needed, simply cut the pad with a sharp knife, or shape the pad using a round file or rotary grinder.
- When you are satisfied with the fit, remove the protective paper from the tape strips and carefully install the pad to the hoop, starting at the top center.
- Use some masking or electrical tape to tightly tape the pad to the rollbar hoop for a few days, until the tape has cured.
- Any rough edges can be carefully smoothed out with a hand file or sandpaper. Be aware that there is a “skin” on the padding, and the subsurface will be a more dull color and finish.
- Enjoy!

Vinyl Covers

- After the padding is installed, determine which vinyl is for each side. There is a notch cut in the backside of the vinyl for the brace tube, and the shorter zipper faces the outside of the car.
- It is important to have the sewing “tabs” on the inside of the main seam all facing toward the rear of the car when installing the vinyl. If this is not done, the top seam will look “lumpy” after installation. If this is the case, simply unzip the cover part way, and push the tabs toward the rear.
- Lay the vinyl over the hoop and installed pad. Push the tabs rearward as described in the previous step. Start the shorter zipper which is toward the outside of the car, and zip it all the way down.
- Looking on the back side of the hoop, center the notch in the vinyl so that the notch matches the rear brace tube. While holding the notch in place at the top of the hoop, smooth out the vinyl on the side where the zipper is closed, pulling downward to smooth out any wrinkles.
- The end of the vinyl should now be slightly above the seat belt tab. Mark the end of the vinyl on the padding. Pull the bottom end of the vinyl up slightly, and cut the padding on the line, using a sharp knife. Pull the vinyl down again, and tightly tie the nylon cord so that it pulls the vinyl slightly around the end of the padding.
- Repeat the previous steps for the second zipper, pulling the vinyl tight from end to end before cutting the padding and tying the second cord. The object is for the zippers to pull that vinyl tight around the tubing, and for the nylon cord to keep the vinyl tight from end to end.
- Repeat for the other hoop.

Enjoy!
Ric